www.arctic.ac

Home Charger 4500

User Manual

support.arctic.ac/hc4500

Dear Customer,

Thank you for choosing the ARCTIC Home Charger 4500.

This compact four port fast-charger allows you to charge all your USB devices (including tablets) at the same time. Every single of the four ports comes with its own overload protection and status LED. One thing is for sure, you will sleep easy knowing that your devices are charging safely.

I hope you enjoy the Home Charger 4500 and we at ARCTIC look forward to further enriching your life with our products. If you would like to share how you use ARCTIC's products please do so at https://www.facebook.com/ARCTIC.en

ARCTIC is a fully carbon neutral company and your support helps us to compensate every kilogram of CO_2 we produce. Thank You.
Sincerely,

Magnus Huber
ARCTIC CEO

Home Charger 4500 Functions



Each port delivers up to 2.9A, combined maximum 4.5A

⚠ Home Charger 4500 does not support fast charging of Samsung Galaxy Tab, Samsung Galaxy Note, Hyundai T7S, LG Optimus 7 and Odys Xelio. Samsung Galaxy Tab and Samsung Galaxy Note will report a "not charging" status on their display while actually charging in standard mode.

⚠ Some Blackberry and Nokia Smartphones may only be compatible to the black ports.

Center LED



On
Home Charger 4500 is plugged in and receives power.

Flashing
Your Home Charger is delivering more than 4000mA. Do not add further load. If your devices are not charging, remove some of them from the Home Charger 4500.

Off
No USB devices are plugged and thus, the Home Charger 4500 is not receiving powerin Standby mode. If USB devices are plugged, more than 4500mA was drawn and the Home Charger 4500 activated the over current protection. Unplug all USB devices and add them one by one.

Individual LED Indicators

Each port is represented by an LED

LED Indicator	Status
Slow Flashing	Charging output below 1000mA
On	Charging output between 1100mA and 2000mA
Fast Flashing	Charging output above 2000mA
Off	No devices plugged in or charge complete

Safety Warnings

- Keep out of reach of children
- Keep out of contact with water
- May get hot while in use
- Do not dismantle or modify your Home Charger 4500
- Modifying your Home Charger 4500 voids all warranty's

Like us on facebook
www.facebook.com/ARCTIC.en

© 2014 ARCTIC Switzerland AG. All Rights Reserved.

No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purpose, without the express written permission of ARCTIC Switzerland AG. In no event shall ARCTIC its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.